

HiFlex Preformed Tape

Fast and Convenient to Install Permanent Thermoplastic Tape

INSTALLATION GUIDE



1

Clean application area thoroughly by removing all sand, dirt, chemicals and oily substances.



2

Using a suitable propane torch, remove any moisture present and preheat the area prior to treatment. Use a suitable primer on non asphaltic and aggregate rich surfaces.



3

Remove the packaging and carefully place the HiFlex Tape onto the prepared surface with the glass coated top facing up. Position the tape as accurately as possible and cut to size.



4

Heat the HiFlex Tape using a suitable propane torch keeping the flame approximately 20-40cm from the tape. Do not concentrate the heat in one area and heat with an even sweeping action. Heat until the tape starts bubbling and flowing into the road surface.



5

The HiFlex Tape should cool and harden within 5-10 minutes. When cooled, examine the tape and test by trying to lift. If areas do lift, repeat step 4.